



Instructions for Catalog # AQC005 USEPA Test Code 16

Revision 090119

Organism: Fathead minnow (*Pimephales promelas*)

Test Conditions: 7-day Chronic, Daily Renewal, 20% Diluted Mineral Water (DMW)

Description:

- This reference toxicant is designed for the Fathead minnow (*Pimephales promelas*), 7-day Chronic, Daily Renewal, 20% Diluted Mineral Water (DMW), Survival and Growth Test (i.e., USEPA Test Code 16, USEPA Method Code 1000.0).
- This reference toxicant is packaged in a 500 mL bottle containing approximately 500 mL of standard concentrate.
- This concentrate can be stored at room temperature.
- This product is intended to be used as a quality control check of the entire analytical process for the analytes/matrix included in the standard.
- The dilution instructions below represent the minimum suggested sample size for this product. Using a smaller sample size may invalidate the assigned value and/or uncertainty shown on the certificate of analysis.
- The certified values apply to the diluted sample after following the stated dilution instructions.

Helpful Hints:

- This reference toxicant has been prepared as a concentrate and must be diluted prior to analysis to prepare a “simulated” effluent (hereafter referred to as the effluent).
- This reference toxicant must be diluted with 20% Diluted Mineral Water (DMW) prepared from Millipore Milli-Q® deionized water (or equivalent) and mineral water, as specified in the current version of the USEPA methods manual.
- The diluted effluent should be utilized as soon as possible after preparation.

Instructions:

1. Add approximately 1.8 Liters of 20% diluted mineral water (DMW) to a clean, dry, 2.0 Liter, class A volumetric flask.
2. Shake the reference toxicant concentrate bottle prior to opening.
3. Using a clean, dry, 50 mL, class A volumetric flask, carefully transfer 50 mL of the reference toxicant concentrate into the 2.0 L flask.
4. Rinse the 50 mL flask into the 2.0 L flask using DMW.
5. Dilute the 2.0 L flask to final volume using DMW.
6. Cap the flask and mix well.

The effluent prepared according to these instructions represents the 100% effluent. See below for secondary dilution instructions:

1. Split the 100% effluent sample into two 1.0 L aliquots. The first aliquot is your 100% effluent for testing.
2. Dilute the second aliquot with 1.0 L of DMW and mix. This is your 50% effluent sample.
3. Continue diluting half of each sample with the same volume of DMW to make your 25%, 12.5% and 6.25% effluent dilutions, which represent all five test dilutions.
4. You are now ready to proceed with the test following your normal procedures.
5. All five test dilutions must be freshly prepared each day of the testing period.

Safety:

ERA products may be hazardous and are intended for use by professional laboratory personnel trained in the competent handling of such materials. Responsibility for the safe use of these products rests entirely with the buyer and/or user. Safety Data Sheets (SDS) for all ERA products are available through our website www.eraqc.com.